



1. Place magnet housing on the frame, opposite to hinge side or above under the horizontal part of the frame.
2. Drill and thread 2x M5 holes according to the measurements.
3. Screw the magnet part to the frame.
4. Attach the magnet plate in line with magnet part min 11mm from the glass edge. Note! Important to follow the tape instruction: Application UHB from Sikab, the glass must be absolutely clean and tape has to rest before any force is applied.
5. The magnetic holding force is by default about 35N, if adjustment of magnetic force is desired, adjust both the adjusting screws equally. Tighten the screws reduces force and unscrew increases. Note, do not exceed the maximum dimension of 8mm.

